

Power wash a Chromebook

1. Press and hold **ESC + Refresh**



and **Power**



for a few seconds.



2. On the "Please insert a recover USB stick or SD card" screen, press the **CTRL + D** keys.




◀ English ▶




Chrome OS is missing or damaged.
Please insert a recovery USB stick or SD card.

For help visit <http://google.com/chromeos/recovery>


3. On the "To Turn OS verification OFF" screen, press the **ENTER** key.




4. On the "OS Verification is OFF" screen – press the **ENTER** key.



5. The Chromebook will reboot.
6. On the "Welcome" screen, press **Let's go >**.



7. Choose the **GSDGuest** network enter the password: **learning**, then press **Connect**.



9. You will see a progress bar and then the "You are enrolled successfully" screen, press **Done** and then **Next**.



You are enrolled successfully

Your Chromebook has successfully been enrolled for enterprise management by granitesd.org
If this is unexpected, please contact support.

DONE

 Shut down

INTL    11:34

10. Chromebook should be ready for a new user to sign in.

Sign in using your student email address (student number@graniteschools.org) and your password.